



LC RF CONTROL 24V RGBW/TW





	EAN	l x w x h [mm]	V	Input signal	IP	(°C)
LC RF CONTROL 24V RGBW/TW	4058075435834	114 x 38 x 20	12-24VDC	2.4 GHz	20	-30...+55




[mm]
114
38
20


INPUT
OUTPUT
Power+
Power-
DC socket
LED indicator
Match key
LED+
Red LED-
Green LED-
Blue LED-
Warm White LED-
Cold White LED-
LEDVANCE
LC RF CONTROL 24V RGBW/TW
RGBW + TW 5CH
LED Controller
2,4GHz wireless control
RUN
MATCH


A: Power Supply
LN
Power Supply
12-24VDC
Constant Voltage
LC RF CONTROL
24V RGBW/TW
MATCH
10 sec: a:RGBW; b:TW
15 sec: RGBW+TW ✓
(➡ Factory settings*)
RGBW+TW LED STRIP
B: Power Adapter
12-24VDC
DC socket
input
LC RF CONTROL
24V RGBW/TW
MATCH
10 sec: a:RGBW; b:TW
15 sec: RGBW+TW ✓
(➡ Factory settings*)
RGBW+TW LED STRIP



1x
2x
3x
4x
5x
6x
7x
8x
9x
10x

LEDVANCE


LC RF REMOTE RGBW
EAN 4058075435858




LC RF REMOTE TW
EAN 4058075435926




LC RF TOUCH PANEL RGBW
EAN 4058075435896




LC RF TOUCH PANEL TW
EAN 4058075435940





A



B







* Ⓓ ZURÜCKSETZEN ⒼⒷ RESET Ⓕ RÉINITIALISER Ⓘ RESET Ⓔ RESET Ⓟ REINICIAR ⒼⓇ ΕΠΑΝΑΦΟΡΑ ⓃⓁ RESET Ⓢ ÅTERSTÄLLNING ⒻⒾ NOLLAUS Ⓝⓞ NULLSTILL ⓈⓀ NULSTIL ⒸⓏ RESET ⓇⓊ СБРОСИТЬ Ⓗⓤ RESET ⓅⓁ RESETUJ ⓈⓀ RESET ⓈⓁⓄ PONASTAVI ⓉⓇ SIFIRLAMA ⒽⓇ PONOVNO POSTAVLJANJE ⓇⓄ RESETARE ⒷⒼ ЗАНУЛЯВАНЕ ⒺⓈ LÄHTESTA ⓁⓉ ATKURTI ⓁⓋ ATIESTATĪT ⓇⓈ RESETUJ ⓊⒶ СКИНУТИ ⓀⓏ ҚАЙТА ОРНАТУ

Technische Unterstützung / Technical support: www.ledvance.com
Kundenservicecenter / Service Center: kundenservice@ledvance.com
Deutschland: Tel.: +49 89 780673-660, Fax: +49 89 780670-665
Österreich: Tel.: +43 1 68068 118 oder 126, Fax: +43 1 68068 7

LEDVANCE GmbH
Steinerne Furt 62
86167 Augsburg, Germany
www.ledvance.com

ⒼⒷ LEDVANCE Ltd, Aquila House
Delta Crescent, Westbrook, Warrington
WA5 7NR, United Kingdom

C10449057
G11142742
03.05.22